



The CD Oxygen cylinder valve is **closed**
The valve is turned clockwise




The CD Oxygen cylinder valve is **opened**
The valve is turned anti-clockwise



The flow valve is turned **OFF**
 (Notice flow valve is on **zero**)



The flow valve is turned on to **1 litre per minute**



A new CD Oxygen cylinder with **red valve seals**



A CD cylinder on side displaying **contents gauge**.
The contents gauge needle indicates that the cylinder is full
(green).

Red seals indicate that the cylinder has been re-filled with 100% oxygen and is full. If there are no seals, the cylinder has been used.

- Check the contents gauge to see how much oxygen is remaining.

Before turning on the flow valve at the top, ensure the grey valve on the side of the cylinder is turned on (turn anti-clockwise). If the valve is closed oxygen will not flow.

- Check amount of oxygen remaining in cylinder by looking at the contents gauge.

If the gauge needle is close to the **red marker**, replace the cylinder for a full cylinder.